

SANI-TANK Handy Guide I

Which mode to use and when	Indicator lights
<p>Auto mode: In an area where discharge is allowed, press the auto button; the SANI-TANK will automatically discharge the holding tank when it reaches 80% full.</p>	<p><i>Auto</i> light on.</p> <p><i>Pump</i> light on while pump runs.</p>
<p>Off mode: In an area where discharge is NOT allowed, press the off button; the SANI-TANK will allow toilet flushes, but won't discharge. The alarm will beep when the tank is 80% full. When the tank reaches 95%, the toilet/s will be disabled and the alarm will beep. The tank needs to be emptied to re-enable toilet flushing (e.g. press auto or manual when back in a discharge area). Mute alarm with alarm mute button.</p>	<p><i>Off</i> light on.</p> <p><i>Hi level</i> light is on (steady), the tank is 80% full.</p> <p><i>Hi level</i> light flashes, the tank is 95%.</p> <p><i>Alarm mute</i> light is on when alarm has been muted.</p>
<p>Manual mode: To discharge holding tank (in an area where discharge is allowed), press manual button. Tank will empty and system will enter Off mode. Select Auto if in an area where discharge is allowed.</p>	<p><i>Manual</i> and <i>Pump</i> lights are on while discharging; <i>Off</i> light comes on when tank is empty (system defaults to Off mode).</p>
<p>Before entering a nil-discharge area: While still underway, empty the Holding Tank by pressing the manual button. Once the Holding Tank is empty, the system defaults to Off mode, which is the correct mode for a nil-discharge area. Press Auto after leaving the nil-discharge area.</p>	<p><i>Manual</i> and <i>Pump</i> lights are on while discharging; <i>Off</i> light comes on when tank is empty (system defaults to Off mode).</p>

SANI-TANK II Handy Guide I

Which mode to use and when	Indicator lights
<p>Auto mode: In an area where discharge is allowed, press the auto button; the SANI-TANK will automatically discharge holding tank when it reaches 80%.</p>	<p><i>Auto</i> light on.</p> <p><i>Pump</i> light on while pump runs.</p>
<p>Off mode: In an area where discharge is NOT allowed, press the off button; the SANI-TANK will allow toilet flushes, but won't discharge. The alarm will beep when the tank is 80% full. When the tank reaches 95%, the toilet/s will be disabled and the alarm will beep. The tank needs to be emptied to re-enable toilet flushing (e.g. press auto or manual when back in a discharge area). Mute alarm with alarm mute button.</p>	<p><i>Off</i> light on.</p> <p><i>Hi level</i> light is on (steady), the tank is 80% full.</p> <p><i>Hi level</i> light flashes, the tank is 95%.</p> <p><i>Alarm mute</i> light is on when alarm has been muted.</p>
<p>Manual mode: To discharge holding tank (in an area where discharge is allowed), press manual button. Tank will empty and system will enter Off mode. Select Auto if in an area where discharge is allowed.</p>	<p><i>Manual</i> and <i>Pump</i> lights are on while discharging; <i>Off</i> light comes on when tank is empty (system defaults to Off mode).</p>
<p>Before entering a nil-discharge area: While still underway, empty the Holding Tank by pressing the manual button. Once the Holding Tank is empty, the system defaults to Off mode, which is the correct mode for a nil-discharge area. Press Auto after leaving the nil-discharge area.</p>	<p><i>Manual</i> and <i>Pump</i> lights are on while discharging; <i>Off</i> light comes on when tank is empty (system defaults to Off mode).</p>

SANI-TANK Handy Guide II																									
What do the lights and alarm mean?	What do I do?																								
<p>Alarm buzzer sounds and Hi level light is on (steady): The alarm sounds when the system is in Off Mode (e.g. in a nil-discharge area) and the Holding Tank is 80% full.</p> <p>Alarm buzzer sounds and Hi level light flashes: The Holding Tank is now 95% full. Toilets will be disabled until the tank is emptied in an area where discharge is allowed.</p>	<p>This is an indication that the Holding Tank is nearly full. Mute the alarm and limit toilet use if remaining in the nil-discharge area.</p> <p>Don't use toilet/s until vessel leaves the nil-discharge area. Then press auto button to empty tank and re-enable toilet/s.</p>																								
<p>Toilets won't flush, Hi-level light is flashing, Alarm mute light is on (steady): The system is in Off Mode and tank has reached 95% of its capacity. This disables Toilet flushing. The alarm has been muted.</p>	<p>Don't use toilet/s until vessel leaves the nil-discharge area. Then press auto button to empty tank and re-enable toilet/s.</p>																								
<p>Indicator light summary</p> <table style="width: 100%; border: none;"> <tr> <td style="width: 33%;"><i>Power</i> light on:</td> <td style="width: 33%;"><u>Steady:</u> System has power.</td> <td style="width: 33%;"><u>Flashing:</u> Supply voltage too low.</td> </tr> <tr> <td><i>Cell</i> light on:</td> <td><u>Steady:</u> Cell is making disinfectant.</td> <td><u>Flashing:</u> Fault in Cell/Cell Tank.</td> </tr> <tr> <td><i>Hi-level</i> light on:</td> <td><u>Steady:</u> Holding tank 80% full.</td> <td><u>Flashing:</u> 95% full, toilets disabled.</td> </tr> <tr> <td><i>Pump</i> light on:</td> <td><u>Steady:</u> Discharge pump running.</td> <td><u>Flashing:</u> Fault in Discharge Pump.</td> </tr> <tr> <td><i>Off</i> light on:</td> <td><u>Steady:</u> Off mode, Holding Tank will NOT discharge automatically.</td> <td></td> </tr> <tr> <td><i>Auto</i> light on:</td> <td><u>Steady:</u> Auto mode; Tank automatically discharges when 80% full.</td> <td></td> </tr> <tr> <td><i>Manual</i> light on:</td> <td><u>Steady:</u> Manual mode, discharging tank. <u>Flashing:</u> Cleansing cycle.</td> <td></td> </tr> <tr> <td><i>Alarm mute</i> light on:</td> <td><u>Steady:</u> Beeping alarm has been muted.</td> <td></td> </tr> </table>		<i>Power</i> light on:	<u>Steady:</u> System has power.	<u>Flashing:</u> Supply voltage too low.	<i>Cell</i> light on:	<u>Steady:</u> Cell is making disinfectant.	<u>Flashing:</u> Fault in Cell/Cell Tank.	<i>Hi-level</i> light on:	<u>Steady:</u> Holding tank 80% full.	<u>Flashing:</u> 95% full, toilets disabled.	<i>Pump</i> light on:	<u>Steady:</u> Discharge pump running.	<u>Flashing:</u> Fault in Discharge Pump.	<i>Off</i> light on:	<u>Steady:</u> Off mode, Holding Tank will NOT discharge automatically.		<i>Auto</i> light on:	<u>Steady:</u> Auto mode; Tank automatically discharges when 80% full.		<i>Manual</i> light on:	<u>Steady:</u> Manual mode, discharging tank. <u>Flashing:</u> Cleansing cycle.		<i>Alarm mute</i> light on:	<u>Steady:</u> Beeping alarm has been muted.	
<i>Power</i> light on:	<u>Steady:</u> System has power.	<u>Flashing:</u> Supply voltage too low.																							
<i>Cell</i> light on:	<u>Steady:</u> Cell is making disinfectant.	<u>Flashing:</u> Fault in Cell/Cell Tank.																							
<i>Hi-level</i> light on:	<u>Steady:</u> Holding tank 80% full.	<u>Flashing:</u> 95% full, toilets disabled.																							
<i>Pump</i> light on:	<u>Steady:</u> Discharge pump running.	<u>Flashing:</u> Fault in Discharge Pump.																							
<i>Off</i> light on:	<u>Steady:</u> Off mode, Holding Tank will NOT discharge automatically.																								
<i>Auto</i> light on:	<u>Steady:</u> Auto mode; Tank automatically discharges when 80% full.																								
<i>Manual</i> light on:	<u>Steady:</u> Manual mode, discharging tank. <u>Flashing:</u> Cleansing cycle.																								
<i>Alarm mute</i> light on:	<u>Steady:</u> Beeping alarm has been muted.																								

SANI-TANK Handy Guide II																									
What do the lights and alarm mean?	What do I do?																								
<p>Alarm buzzer sounds and Hi level light is on (steady): The alarm sounds when the system is in Off Mode (e.g. in a nil-discharge area) and the Holding Tank is 80% full.</p> <p>Alarm buzzer sounds and Hi level light flashes: The Holding Tank is now 95% full. Toilets will be disabled until the tank is emptied in an area where discharge is allowed.</p>	<p>This is an indication that Holding Tank is nearly full. Mute the alarm and limit toilet use if remaining in the nil-discharge area.</p> <p>Don't use toilet/s until vessel leaves the nil-discharge area. Then press auto button to empty tank and re-enable toilet/s.</p>																								
<p>Toilets won't flush, Hi-level light is flashing, Alarm mute light is on (steady): The system is in Off Mode and tank has reached 95% of its capacity. This disables Toilet flushing. The alarm has been muted.</p>	<p>Don't use toilet/s until vessel leaves the nil-discharge area. Then press auto button to empty tank and re-enable toilet/s.</p>																								
<p>Indicator light summary</p> <table style="width: 100%; border: none;"> <tr> <td style="width: 33%;"><i>Power</i> light on:</td> <td style="width: 33%;"><u>Steady:</u> System has power.</td> <td style="width: 33%;"><u>Flashing:</u> Supply voltage too low.</td> </tr> <tr> <td><i>Cell</i> light on:</td> <td><u>Steady:</u> Cell is making disinfectant.</td> <td><u>Flashing:</u> Fault in Cell/Cell Tank.</td> </tr> <tr> <td><i>Hi-level</i> light on:</td> <td><u>Steady:</u> Holding tank 80% full.</td> <td><u>Flashing:</u> 95% full, toilets disabled.</td> </tr> <tr> <td><i>Pump</i> light on:</td> <td><u>Steady:</u> Discharge pump running.</td> <td><u>Flashing:</u> Fault in Discharge Pump.</td> </tr> <tr> <td><i>Off</i> light on:</td> <td><u>Steady:</u> Off mode, Holding Tank will NOT discharge automatically.</td> <td></td> </tr> <tr> <td><i>Auto</i> light on:</td> <td><u>Steady:</u> Auto mode; Tank automatically discharges when 80% full.</td> <td></td> </tr> <tr> <td><i>Manual</i> light on:</td> <td><u>Steady:</u> Manual mode, discharging tank. <u>Flashing:</u> Cleansing cycle.</td> <td></td> </tr> <tr> <td><i>Alarm mute</i> light on:</td> <td><u>Steady:</u> Beeping alarm has been muted.</td> <td></td> </tr> </table>		<i>Power</i> light on:	<u>Steady:</u> System has power.	<u>Flashing:</u> Supply voltage too low.	<i>Cell</i> light on:	<u>Steady:</u> Cell is making disinfectant.	<u>Flashing:</u> Fault in Cell/Cell Tank.	<i>Hi-level</i> light on:	<u>Steady:</u> Holding tank 80% full.	<u>Flashing:</u> 95% full, toilets disabled.	<i>Pump</i> light on:	<u>Steady:</u> Discharge pump running.	<u>Flashing:</u> Fault in Discharge Pump.	<i>Off</i> light on:	<u>Steady:</u> Off mode, Holding Tank will NOT discharge automatically.		<i>Auto</i> light on:	<u>Steady:</u> Auto mode; Tank automatically discharges when 80% full.		<i>Manual</i> light on:	<u>Steady:</u> Manual mode, discharging tank. <u>Flashing:</u> Cleansing cycle.		<i>Alarm mute</i> light on:	<u>Steady:</u> Beeping alarm has been muted.	
<i>Power</i> light on:	<u>Steady:</u> System has power.	<u>Flashing:</u> Supply voltage too low.																							
<i>Cell</i> light on:	<u>Steady:</u> Cell is making disinfectant.	<u>Flashing:</u> Fault in Cell/Cell Tank.																							
<i>Hi-level</i> light on:	<u>Steady:</u> Holding tank 80% full.	<u>Flashing:</u> 95% full, toilets disabled.																							
<i>Pump</i> light on:	<u>Steady:</u> Discharge pump running.	<u>Flashing:</u> Fault in Discharge Pump.																							
<i>Off</i> light on:	<u>Steady:</u> Off mode, Holding Tank will NOT discharge automatically.																								
<i>Auto</i> light on:	<u>Steady:</u> Auto mode; Tank automatically discharges when 80% full.																								
<i>Manual</i> light on:	<u>Steady:</u> Manual mode, discharging tank. <u>Flashing:</u> Cleansing cycle.																								
<i>Alarm mute</i> light on:	<u>Steady:</u> Beeping alarm has been muted.																								